

1. Overview

This module is used to 17s~32s cell pack, provide charge and discharge control,

2-1 for mechanical figure

Figure 2-1

6	20	485_1B	RS485_1 Interface B Line	20AWG
---	----	--------	--------------------------	-------

